"Never let to dream and believe in you"

INSTRUCTIONS G-FIT IN ENGLISH

"Welcome to G-FIT, the new generation of activity and sleep


bracelets with which children will have fun exercising and creating healthy habits"

INTRODUCTION | OPTIONS | CONSUMER |

Locate two golden circles on the lower back of the sports band. Take the charger out of


CHARGE YOUR DEVICE

the box and bring it close to the circles, you will notice that they become magnetized, make sure it does not come loose and charge it on any USB power adapter. The device may take 1-2 hours to charge.









phone or your children's, available for iOS and Android.

some of the functions.

DOWNLOAD "RUNMIFIT"

Accept the permissions requested by the application, otherwise it will not execute

Download the free Runmifit APP on your

where you have installed Runmifit. The pairing must be done from the application, not from the bluetooth settings.

LINK YOUR DEVICE

With your watch nearby, open Runmifit and go to "Device", then search for "Add device" and accept the location permissions.

Refresh the search page and select your

Activate Bluetooth on the mobile phone

device named S90-xxxx. Once paired it will start to sync the data, it will take a few seconds.

If you cannot find it when pairing G-FIT with the APP, it is possible that the permissions are not active or that your device is already linked to another mobile phone.



must link and unlink the device each time you need it.

for at least a week. **Unpair your G-FIT from Runmifit to use it on another** mobile device.


To read data from different G-FITs in

the same Runmifit account, you

The data will be saved in your G-FIT

Introduction to use

Adjust the band no more than one finger's length from the wrist bone.



Collocation


For more precision, place the G-FIT in your non-dominant hand. Being right-handed place to the left and to the right for lefties.

Adjust it to the diameter of the wrist without being too tight, but not loose either.

Your G-FIT resists water during a short

exposure so you won't have to worry about

washing your hands or showering.



to start the activity, press once to pause it, or

hold again for 3 seconds to end it.

Click on the control area (1.) that you will find

at the bottom of the screen to turn the page.

Press and hold the control area for 3 seconds

2. Charging connector **Activate notifications** Receive the notifications that the mobile

format and notification numbering.

phone receives on your G-FIT in short text

getting it wet and above all do not use it for

cleaner on a regular basis.

water sports. If you notice that the device has stopped

Your G-FIT is water resistant but avoid

charging connector (2.) with a little alcohol or hydroalcoholic gel.

charging and won't turn on, clean the



permissions of SMS, calls, contacts and access to notifications.

You can block this option at any time and choose the type of notifications you want to receive.

Open Runmifit and access "Device" then

look for the Notifications option, accept the

phone must have Bluetooth active and be close to your G-FIT band.

Remember that to receive notifications, the

HEALTH



press and hold to restore. Restore Measures the amount of If you cannot find your phone, press and hold to oxygen carried by the activate the Smartphone blood compared to its total capacity.

SPORT



Walking

Climbing

Skating

Tracking of physical

activity while walking.

Monitoring of physical

activity while hiking.

S90-XXXX

03S90N7

Device Name

and version.

Shut down


Information about your

G-FIT: name, registration

Switch off the device if



Skating



contact@gualaru.com

+34 644 698 292

Contact

situation.

costs.

Football Tracking physical activity while playing football.

More

More

Chrono-

metre

Find

Phone

Football

Basketball

Running

To access the other

Stopwatch

Find phone

vibration.

features of your G-FIT.

Start timing your activity,

press once to pause and

Basketball Tracking physical activity

while playing basketball.

Running Monitoring of physical Tracking physical activity activity while skating. while running. Up to 16 sport modes

defects. **Process a repair Express return**

you need to arrange a repair, please contact our assistants via WhatsApp or Email indicating the order number and providing video or photographic evidence of your

We have an open chat via WhatsApp to solve

our customers' doubts or to process repairs.

If you have problems with your device and

damaged products you will have to pay the

transport costs plus possible additional

Warranty does not apply

For factory defects the replacement or repair will be free of charge. For configuration of the device or for

Gualaru reserves the right to waive the costs for devices that have been submerged in water or liquids, have been knocked, the SIM card has been inserted incorrectly or the motherboard has been accessed and the warranty seal has been broken.

If the product does not meet your needs, you can request an express return within 14 days of receiving your order.

Warranty

The device must be in the same condition in which you received it from Gualaru. The economic refund of the order will be made within a maximum of 3 working days of receipt of the device. Remember that it can take up to 10 days for the payment to be registered in

Gualaru Always On S.L. complies with the

European Trade Regulations according to

which you have the right as a consumer to a

three-year warranty for manufacturing

After 14 days of silence from Gualaru you can claim the replacement of the device or refund of the order.

The technical team has 14 working days to

check and repair your device after shipment.

Do not wear your G-FIT in hot places such as saunas, hot springs steam or long ex-

IP68 resistant to moisture and sweat. Avoid getting your device wet. Do not use your G-FIT for showering or water sports.

posure to high temperatures.

your bank.

Repair time

Frequently Asked Questions (FAQ)

If you have two devices you may need to know the full name to identify them in the App. To do this, log in to your G-FITI and

> for Bluetooth and you will see the full name starting with S90-.

••• the

Make sure your device is not linked to another Runmifit account. Make sure you have accepted permissions of the App.

RIATE III

Why can't I find my device in "Add How do I identify the full name of my **Device**" in Runmifit? **G-FIT?** You must pair to the device through the App not from your mobile phone's Bluetooth settings. If you have already done this simply navigate to the "MORE" option, then search turn off Bluetooth on your phone and turn it back on, this time search from the Runmifit App. Make sure your device is turned on.